

WARRANTY

Welcome to the Westcott Family!

Whether this is your first or fifth Westcott product, we greatly appreciate your business.

The Rapid Box is just one of many lighting modifiers brought to you by The F.J. Westcott Company.

Visit fjwestcott.com for:

- Product Videos & Tips
- Photo & Video Inspiration
- Product Reviews & Support
- Knowledge Base & FAQ
- Registering a Product

We hope you enjoy your new gear!

Sincerely,
Team Westcott



One year against manufacturer defect.

Westcott's warranty obligations for this product are limited to the terms set forth below: The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the "Westcott" trademark, trade name, or logo affixed to them.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; (b) to damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) to a product or part that has been modified to alter functionality or capability without the written permission of Westcott.; or (d) to cosmetic damage, including but not limited to scratches, dents and broken plastic.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the ONE (1) YEAR limited warranty will be returned at the expense of the sender.

Register this product at FJWESTCOTT.COM/WARRANTY

Repair Dept.: 800-886-1689 / 419-243-7311 (International)

E-Mail: INFO@FJWESTCOTT.COM SUBJECT: ATTN: REPAIR DEPT.

Shipping: F.J. Westcott Co, 1425-B Holland Rd, Maumee, OH 43537

©F.J. WESTCOTT CO. ALL RIGHTS RESERVED. AU140219

the
RAPIDBOX™

QUICK START GUIDE

OCTA
OCTA-MINI
STRIP



SETUP & USAGE



THE RAPID BOX



DIFFUSION PANEL



BRACKET



CARRY CASE


*Note: Instructions are shown using Octa model.
Setup is the same for all Rapid Box units.*

Step 1.

Remove contents from the box.

Step 2.

Hold The Rapid Box in one hand using the rear silver speedring. Undo the Velcro strap around the The Rapid Box and fully open the unit. With the opposite hand, press down on the runner towards the center pole and slide into place. Rotate slightly to lock into place. *SEE FIG. 1 & FIG. 2*



HINT: The grooves inside of the runner should connect with two projecting parts in the center pole base. When the runner and center pole base grooves are connected, all the ribs of the box should be straight. *SEE FIG. 3, FIG. 4 AND FIG. 5.* If they don't connect perfectly, rotate the runner slightly until you feel it lock in place. (If this does not happen, the stretchers will twist and cause stress on the hinges that could cause damage).




FIG. 3




FIG. 4

FIG. 5

Step 3.

On the back of The Rapid Box, locate the two pins. Press down on the longer pin and rotate the bracket until it locks into place. *SEE FIG. 6, FIG. 7 AND FIG. 8*



FIG. 6



FIG. 7




FIG. 8

Step 4.

Locate the shoe mount tilter bracket. Tighten screw to attach tilter bracket to swing arm. Attach The Rapid Box to a light stand. *SEE FIG. 9*




FIG. 9



Step 6.

Locate the speedlite shoe mount on the tilter bracket. Loosen the tension screw to affix your speedlite. After attaching the speedlight, tighten tension screw. Use the tightening mechanism found on your speedlite for a secure fit. *SEE FIG. 11*




FIG. 11

Step 7.

Adjust the bracket accordingly until the head of your speedlite fits into the opening of The Rapid Box. *SEE FIG. 12.*




FIG. 12




FIG. 10